19 Fuel Receivers

All FloMAX Fuel receivers have our patented enclosed poppet stem spring for a smooth and higher flowing fuel path. This greatly enhances the life of both the receiver and fuel nozzle due to the decrease in fuel restriction and vibration.

Our FR-RS series of fuel receivers have a patented removable stainless steel wear sleeve. This revolutionary patented concept allows the fuel receiver wear surface to be replaced very quickly and easily without removing the fuel receiver from the tank or the loss of any fuel. It uses the same internal spring concept that has been so successful in our other receivers.

• Patented internal spring reduces vibration and increases flow. • Patented removable wear sleeve allows easy replacement without draining tank (FR-RS Only). • Available in both standard and low pressure models.

FRX-C 2”



FR-RS



FRA-AT-C



FRS-61



Part No.	Description
FRS	Fuel Receiver - Steel
FRS-C	Fuel Receiver - Steel with Cap
FRA	Fuel Receiver - Aluminum
FRA-C	Fuel Receiver - Aluminum With Cap
FRA-AT	Fuel Receiver Aluminum - Anti Theft
FRA-AT-C	Fuel Receiver Aluminum - Anti Theft with Cap
FR-RS	Fuel Receiver w/Removable Sleeve
FR-RS-AT	Fuel Receiver w/Removable Sleeve - Anti Theft
FR-RS-AT-C	Fuel Receiver w/REM Sleeve - Anti Theft with Cap
FR-RS-R	Fuel Receiver w/REM Sleeve - Replacement Sleeve

Part No.	Description
FRA-NI*	Fuel Receiver Non-Interchangble
FRA-NI-C*	Fuel Receiver Non-Interchangble, with Cap
FRX	Fuel Receiver 2”
FRX-C	Fuel Receiver 2” with Cap
FRX Cap	Fuel Receiver 2” Cap
FRX P Cap	Fuel Receiver Cap - Push -On Mechanically Locking
FR Cap	Fuel Receiver Cap
FR P Cap	Fuel Receiver Cap - Push -On Mechanically Locking
FRS-61	Stainless Fuel Receiver Code 61 Flange
FRS-61-C	Stainless Fuel Receiver Code 61 Flange w/Cap

* USE WITH FNBL-NI ONLY See Page 4

INDORATA POWER ENERGI

FR-P Cap



FR-P Cap and FRX-P Cap Available. Spring Clip Option Available For All Fuel Receivers.

FR P Cap and FRX P Cap are a Flomax innovation for an easily installed and removed fuel receiver cap. The push to connect design allows easy installation in all weather conditions. The FR P cap fits all standard fuel receivers. The FRX P Cap fits our high flowing 2” FRX Fuel receivers.